

Rajshahi University of Engineering & Technology

Department of Electrical & Computer Engineering

Lab Report

Experiment No: 03

Name of the experiment: Study of the power measurement of a $3-\phi$ balanced system using two wattmeter method.

Course Code	ECE 1201
Course Title	Circuit & Systems II Sessoinal
Date of experiment	17.09.2024
Date of Submission	01.10.2024

Submitted By:	Submitted To:				
Name : Nur Nafis Fuad Roll : 2210032	Oishi Jyoti				
Registration: 1086	Assistant Professor Department of ECE, RUET				
Session : 2022-2023					
Department of ECE, RUET					

Experiment No: 03

- **1. Name of The Experiment:** Study of the power measurement of a 3ϕ balanced system using two wattmeter method.
- **2. Objectives:** This lab's goal is to examine and validate the power measurement of a $3-\varphi$ balanced system using two wattmeter method.

3. Theory:

In a three-phase balanced system, there are three lines from the source. So, It is obvious that, three wattmeters have to be connected to three line to measure the power draw. But calculation shows that it is enough to calculate two wattmeters to calculate total power draw from a $3-\varphi$ balanced system.

Here, the power draw of the system, $P = \sqrt{3}VLILcos\Theta$ where, $\Theta = cos\{tan^{-1}\left(\sqrt{3}\frac{W_1 - W_2}{W_1 + W_2}\right)\}$

4. Required Apparatus:

- 1. Source
- 2. VARIAC
- 3. Wattmeter
- 4. Ammeter
- 5. Resistor
- 6. Multimeter
- 7. Connecting wires

5. Circuit Diagram:




Figure: Circuit Diagram for a Balance 3 Phase System

6. Data Table & Result:

Sl No.	P ₁ (W)	P ₂ (W)	$P_t = P_1 + P_2$ (W)	V _L (V)	I _L (A)	$\begin{array}{c} P_c = \\ \sqrt{3 \ V_L \ I_L} \\ \scriptscriptstyle (W) \end{array}$	$\mathbf{Error} = \frac{ P_t - P_c }{P_t} \times 100$ (%)
01	24	24	48	55	0.544	51.823	7.96
02	41	41	82	70	0.661	80.141	2.32
03	62	62	124	85	0.788	116.010	6.44
04	82	82	164	102	0.900	159	3.04

51	P, \	PZ	P = P + P	VL	JL	P(1)=13 V.I.	1.e
1	24	24	48	55	0.244	51.823	7.96
2	49	49	p2	70	0.661	90.141	3-37
3	62	62	- 124	85.	0.758	116.01	6.49
4	82	89	169	102	00	156)	Q=3-4
Roll: 31	07		¥.0974			1	3.00

7. Result:

Average percentage of error: 4.94 %

8. Discussion:

The experiment measured power in a three-phase balanced system using the two wattmeter method. The setup involved connecting a three-phase load to the supply and calibrating the wattmeters. After energizing the circuit, readings were recorded, and total power was calculated as

$$P_t = P_1 + P_2$$

Overall, the experiment confirmed that the two wattmeter method is an effective and reliable technique for measuring power in three-phase balanced systems.

9. Precautions:

- i. All connection should be perfectly connected.
- ii. Before connecting the instruments check their zero reading.
- iii. The terminal of the resistance should be properly connected.

10. Reference:

(i) Charles K. Alexandar and Matthew N. O. Sadiku, "Fundamentals of Electric Circuit", 5th Edition, 1221 Avenue of the Americas, New York